

SYMBOL NOTE

SYM.	PURPOSE	WEIGHT	NOTE
A	PLANCARD BATTEN		
B	COVER CURTAIN		
C	NO.1 SUSPENSION	300	
D	NO.1 SET BATTEN	300	
E	NO.1 DRAW CURTAIN		
F	ROLL SCREEN		
G	NO.2 SUSPENSION	300	
H	NO.2 SET BATTEN	300	
I	NO.2 DRAW CURTAIN		
J	NO.3 SUSPENSION	300	
K	NO.3 SET BATTEN	300	
L	NO.3 DRAW CURTAIN		
M	NO.4 SUSPENSION	300	
N	NO.4 SET BATTEN	300	
O	NO.5 SUSPENSION	300	
P	PROJECTION SCREEN		

서빛마루문예회관 단면 배치도